

DATA**INSTRUCTIONS TO DRIVERS**

1. Have a 25 litre container of clean water on your wagon for use in emergencies.
2. You must carry this data sheet in your cab along with any other data sheets relevant to the load you are carrying and show them on demand to any Police Officer or to any Traffic Examiner.
3. If this product is not on your present load then this transport data sheet may be kept in your cab but it must not be with the other sheets for the products which you are carrying. It should be kept in a separate place or file and marked clearly "NOT APPLICABLE TO THIS LOAD".
4. If your load is 0.5 tonne or more (ie. 17 x 25 litre drums) you must display the orange warning plates when the load has been delivered. The warning plates must be clean and clearly visible.
Also when leaving your vehicle you must park in a safe place.
5. If you are carrying any drums marked as corrosive British Flowplant Group instruct that for additional safety and as a voluntary act you should display your orange boards. This is not a legal necessity and you must remove the boards when the chemicals have been delivered.
6. If your total load is 3 tonnes or over then, in addition, when you park you must ensure that there is a responsible person (over 18) in attendance.

IN THE EVENT OF ANY CHEMICAL SPILLAGE OF MORE THAN 1.0 LITRE YOU SHOULD INFORM THE POLICE AND FIRE BRIGADE.

FOR THE CARRIAGE OF DANGEROUS SUBSTANCES**NATURE OF THE HAZARD**

This product is a mixture and contains hydrocarbon solvents similar to petroleum distillates with a Flash Point of about 55°C.

KEEP AWAY FROM NAKED FLAMES ..FLAMMABLE LIQUID.

It is unpleasant but not particularly harmful on the body.

ACTION TO BE TAKEN IN AN EMERGENCY**FOR SPLASHES ON THE BODY**

- i) Remove contaminated clothing and take care as it will be flammable near a flame.
- ii) Wash splashes off the skin and clothing with plenty of soapy water.
- iii) Wash out the eyes with plenty of clean water.

FOR ACCIDENTAL SPILLAGES

- i) Give warning of the danger.
- ii) Because of the fire hazard notify the POLICE/ FIREBRIGADE if more than 1.0 litre is involved.
- iii) Contain the spillage using soil or sand and slowly cover it over with soil/sand. After the residue will have to be disposed of safely.
- iv) In the event of fire, use foam or chemical extinguishers.